



SPECIFICATIONS

- 16A, IP21
- Floor, room, dual, PWM, snow melting
- Exxact, Elko, Merten, Impressivo, Jussi, Gira compatible
- The best possible ecodesign rating (40%)
- CE certified, Bluetooth



INSTALLATION

- Connect the wires and push the frame and frame adapter into place
- Turn ON the power
- The thermostat automatically selects a mode. If a floor probe is connected at first start-up → floor mode. Otherwise room thermostat mode.




INSTALLATION IS READY!

BASIC USE


Measured temperature

1. Use knob C° to activate display
2. Use knob C° to modify setpoint
OR use SET to go menu



Setpoint

1. Use knob C° to adjust setpoint
2. Use SET to accept **OR** wait 60 seconds for automatic exit



USER INTERFACE

MENU

Comfort mode

ECO mode

Boosted heating
for an hour

Turn OFF

Mode indication

QR link to
documents

Exit from this menu

Measured temperature (screen
saver)


Measured temperature (active)

SETPOINT

Comfort mode setpoint

ECO mode setpoint

Externally activated
ECO mode setpoint



SETTINGS EASILY WITH MOBILE PHONE



If an installer or user wishes, he can access the advanced functions with the free ecoControl app



In Android phones app may ask your permission for Location Services. Please allow them. The app does not collect the location info but the use of Bluetooth requires that.